



Kit Lock – folding bicycle lockers

- 1. With the indicator in the open position, turn the dials to the factory pre-set combination 0-0-0-0.
- 2. Depress the Reset Button fully and hold, turn the dials to your desired combination.
- 3. Once you have chosen and set your combination, turn the outer casing so the indicator is in the locked position.
- 4. Make a note of your chosen combination and scramble the dials. The lock is now locked.
- 5. To reopen, rotate the dials to your chosen combination and turn the outer casing so the indicator is in the open position.
- 6. If you have an issue with the lockers please report to Marshall Building reception: 0207 107 5760

Lse.Mar.Reception@lse.ac.uk